



# **User's Guide Supplement**

## **Multimedia Projector**

**EB-775F**

**EB-770Fi**

**EB-770F**

**EB-760Wi**

**EB-760W**

## **Introduction to the Updated Firmware 3**

---

**Updates to User Operations (Version 1.10)..... 4**

## **Details of Updated Firmware 5**

---

**Details of User Operation Change (Version 1.10)..... 6**

Default Password Settings..... 6

Setting a Password..... 6

Setting the Remote Password and Web Control Password ..... 7

## **Appendix 8**

---

**Notices..... 9**

Copyright Notice..... 9

General Notice ..... 9

Copyright Attribution..... 9

# Introduction to the Updated Firmware

Epson periodically provides firmware updates to enhance your projector features and to address issues of performance. Refer to these sections to learn more about the updated features within each firmware version.

## ▶ **Related Links**

- "Updates to User Operations (Version 1.10)" [p.4](#)

The following projector operations have changed in firmware version 1.10:

- The default passwords are no longer set for the following functions.
    - **Password Protect**
    - **Epson Web Control**
  - You must set a password for the following functions.
    - **Simple AP**
    - **SNMP**
    - **PJLink**
    - **Crestron Connected**
    - **Command Communication**
  - If the **Remote Password** and the **Web Control Password** have not been set, a screen prompting you to set these passwords is displayed when you select the **Network Settings** menu for the first time.
- » **Related Links**
- "Default Password Settings" [p.6](#)
  - "Setting a Password" [p.6](#)
  - "Setting the Remote Password and Web Control Password" [p.7](#)

# Details of Updated Firmware

Check these sections for the updated details of firmware.

## ▶ **Related Links**

- "Details of User Operation Change (Version 1.10)" [p.6](#)

Refer to these sections for details on changes to user operations.

► **Related Links**


- "Default Password Settings" [p.6](#)
- "Setting a Password" [p.6](#)
- "Setting the Remote Password and Web Control Password" [p.7](#)

## Default Password Settings

No password is set by default. When you use the following functions for the first time, follow the on-screen instructions to set a password.


**Previous Password Settings (Version 1.00)**

Function	Password	Default Password
Password Protect	Password	0000
Epson Web Control > Basic Control	Remote Password	User Name: EPSONREMOTE Password: Projector's serial number
Epson Web Control > other options	Web Control Password	User Name: EPSONWEB Password: Projector's serial number



You can check the projector's serial number on the following screens.

- **Management** menu > **Information**
- **Epson Web Control** screen



**New Password Settings (Version 1.10)**

Function	Password	Default Password
Password Protect	Password	None
Epson Web Control > Basic Control	Remote Password	User Name: EPSONREMOTE Password: None
Epson Web Control > other options	Web Control Password	User Name: EPSONWEB Password: None

## Setting a Password

You must set a password. When you use the following functions for the first time, follow the on-screen instructions to set a password.

Function	Password
Simple AP	Passphrase
SNMP	Community Name

Function	Password
PJLink	PJLink Password
Crestron Connected	Password
Command Communication	Monitor Password



- You can only set the Monitor Password using Epson Web Control.
- If Command Communication fails after you update the projector firmware to version 1.10, set the Monitor Password or the Web Control Password.

---

## Setting the Remote Password and Web Control Password

If the **Remote Password** and the **Web Control Password** have not been set, a screen prompting you to set these passwords is displayed when you select the **Network Settings** menu for the first time. Follow the on-screen instructions to set these passwords.

# Appendix

Refer to these sections for important notices.

## ▶ **Related Links**

- "Notices" [p.9](#)



Check these sections for important notices.

► **Related Links**

- "Copyright Notice" [p.9](#)
- "General Notice" [p.9](#)
- "Copyright Attribution" [p.9](#)

Other product names used herein are also for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

Software Copyright: This product uses free software as well as software to which this company holds the rights.

---

## Copyright Notice

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

The contents of this guide may be changed or updated without further notice.

Illustrations in this guide and the actual projector may differ.

---

## Copyright Attribution

This information is subject to change without notice.

© 2023 Seiko Epson Corporation

Rev.1.0 2023.02 EN

---

## General Notice

EPSON is a registered trademark, and EPSON Exceed Your Vision is a registered logomark of Seiko Epson Corporation.