



Supplemental Guide for Display Status Menu

EH-LS9000B
EH-LS9000W
CH-LS9000B
CH-LS9000W

Terms of Use for "Supplemental Guide for Display Status Menu"

May 2025



Seiko Epson Corporation

1. The copyright of "Supplemental Guide for Display Status Menu" (hereinafter referred to as "this document") belongs to Seiko Epson Corporation (hereinafter referred to as "the company"). You may print one copy of this document and use it only for the purpose of using the company's projector products. You may not reproduce, reprint, modify, or transmit this document, in whole or in part, without prior permission from the company.
2. The content of this document is subject to change without notice. Make sure you understand these points before use.
3. You use this document at your own risk. The company shall not be liable for any direct, indirect, special, incidental, consequential, or other damage resulting from your use of, or inability to use, this document.


Display Status

Category	Item	Description
System		Displays the system status.
	<1/3>	Displays the main status.
	System Status	Displays the operating status of the system.
		OK: The projector is in normal operating mode.
		Warm-Up: The projector is warming up.
		Standby: The projector is in standby mode.
		Cool Down: The projector is cooling down.
		Temp Error: Temperature error due to overheating. Projector has turned off. Leave it turned off to cool down for 5 minutes. <ul style="list-style-type: none">• Make sure that the vents and air filter are not clogged with dust or obstructed by nearby objects.• Make sure the environmental temperature is not too hot.• Clean or replace the air filter. For details, refer to the <i>User's Guide</i>.• If operating the projector at high altitude, set the [High Altitude Mode] setting to [On] in the projector's [Installation] menu.• If the problem persists, unplug the projector and contact Epson for help.
		Fan Error: A fan error has occurred. Turn the projector off, unplug it, and contact Epson for help.
		Sensor Error: Turn the projector off, unplug it, and contact Epson for help.
		Internal Error: An internal error has occurred. Turn the projector off, unplug it, and contact Epson for help.
		Temp Warning: A high temperature warning occurred. <ul style="list-style-type: none">• Make sure that the vents and air filter are not clogged with dust or obstructed by nearby objects.• Clean or replace the air filter.• Make sure the environmental temperature is not too hot.
		Laser Error: Turn the projector off, unplug it, and contact Epson for help.
		Laser warning: Turn the projector off, unplug it, and contact Epson for help.
	Laser Status	Displays the operating status of the light source.
	Last Event	Displays the latest warnings or errors.
	Intake Air Temp	Displays the air intake temperature.
	Internal Temp Lv	Displays the projector's internal temperature in five levels.

Display Status

Category	Item	Description
	<2/3>	Displays the operation time and light source information.
	Operation Time	Displays the projector's total operation time.
	Laser Op. Time	Displays the total operation time of the laser light source.
	<3/3>	Displays the status of the current input source.
	Source	Displays the current source. Display example: HDMI
	Signal Status	Displays the identification results of signals. <ul style="list-style-type: none"> • Available: This signal can be displayed. • No Signal: No signal is being input. • Not supported: An input signal has been detected, but cannot be displayed because it is not supported.
	Resolution	Displays the resolution. Display example 1: 640 x 480: A signal with an effective resolution of 640 pixels (wide) x 480 lines (high) Display example 2: 1920 x 1080: A signal with an effective resolution of 1920 pixels (wide) x 1080 lines (high)
	Refresh Rate	Displays the refresh rate and scanning method. Display example 1: 24p = Refresh Rate 24 [Hz], Scan Mode: Progressive Display example 2: 60i = Refresh Rate 60 [Hz], Scan Mode: Interlace
	ColorSamp./Depth	Displays the color sampling and bit depth. Display example 1: YCbCr444/8bit Display example 2: RGB/10bit  Notes When YCbCr422 is detected at the following input ports, "-" is displayed because the bit depth cannot be analyzed. <ul style="list-style-type: none"> • HDMI
	Color Space	Displays the color space. <ul style="list-style-type: none"> • Auto(**): When set to [Auto], the color space that is automatically determined from the input signal is displayed instead of **. Display example: Auto(BT.709) • BT.709: Displayed when the input signal is being processed using BT.709. • BT.2020: Displayed when the input signal is being processed using BT.2020.  Notes <ul style="list-style-type: none"> • BT.709: Mainly used for DVDs and conventional TV broadcasts. • BT.2020: Mainly used for high-quality image content such as HDR.




Display Status

Category	Item	Description
	Dynamic Range	<p>Displays the dynamic range.</p> <ul style="list-style-type: none"> Auto(**): When set to [Auto], the dynamic range that is automatically determined from the input signal is displayed instead of **. Display example: Auto(SDR) SDR: Displayed when the input signal is being processed using SDR. HDR10: Displayed when the input signal is being processed using HDR10. HDR10+: Displayed when the input signal is being processed using HDR10+. HLG: Displayed when the input signal is being processed using HLG. <p> Notes</p> <ul style="list-style-type: none"> SDR: Mainly used for DVDs and conventional TV broadcasts. HDR10: This is one of the HDR standards and is mainly used for Ultra HD Blu-ray. HDR10+ : This is one of the extended standards of HDR and is mainly used for Ultra HD Blu-rays. Its dynamic metadata allows you to process images dynamically and display images with gradations that are more suitable for each scene than HDR10. HLG: This is one of the HDR standards and is mainly used for TV broadcasts. With a brightness gradient approximately 10 times greater than SDR, this allows you to display realistic images.
	Video Range	<p>Displays the video range.</p> <ul style="list-style-type: none"> Auto(**): When set to [Auto], the video range that is automatically determined from the input signal is displayed instead of **. Display example: Auto(Limited) Limited(16-235): Displayed when the input signal is being processed using Limited. Full(0-255): Displayed when the input signal is being processed using Full. <p> Notes</p> <ul style="list-style-type: none"> Limited(16-235): Usually selected when the input signal is a YCbCr signal. Full(0-255): Usually selected when the input signal is an RGB signal. If images look over-exposed or under-exposed, set [Signal I/O] - [Signal Format] in the projector's menu to [Full (0-255)].
	Frame Interp.	<p>Displays the Frame Interpolation setting.</p> <p>Setting Value: --, Off, Low, Mid, or High</p>
Version		Displays the serial number and firmware version.
	Serial Number	Displays the serial number.
	Main	Displays the embedded software main version.
	Video2	Displays the embedded software version.
	Sub	Displays the embedded software version.
	HDMI	Displays the embedded software version.
	Pixel Shift	Displays the embedded software version.
Network Wired		Displays the wired network status.
	Projector Name	Displays the name used to identify the projector when connected to a network.
	Connection Mode	Displays the connection path for a wired network.
	DHCP	Displays the DHCP settings.
	IP Display	Displays the IP address display settings.
	IP Address	Displays the IP address.



Display Status

Category	Item	Description
	MAC Address	Displays the MAC address.


Display Status

Category	Item	Description
Input Signal		Displays the signal status of the current input source.
	<1/3>	Displays general information about the input signal.
	Sync Detect(5V)	<p>Displays the detection results of 5V signals sent to the connected device.</p> <ul style="list-style-type: none"> Detected: A 5V signal has been detected. Not Detected: A 5V signal has not been detected. <p> Notes</p> <p>If "Not Detected" is displayed, a 5V signal has not been detected. Make sure the device and cables are securely connected.</p>
	Signal Status	<p>Displays the identification results of signals.</p> <ul style="list-style-type: none"> Available: This signal can be displayed. No Signal: No signal is being input. Not supported: An input signal has been detected, but cannot be displayed because it is not supported by this device.
	Resolution	<p>Displays the resolution.</p> <p>Display example 1: 640 x 480: A signal with an effective resolution of 640 pixels (wide) x 480 lines (high)</p> <p>Display example 2: 1920 x 1080: A signal with an effective resolution of 1920 pixels (wide) x 1080 lines (high)</p>
	Refresh Rate	<p>Displays the refresh rate and scanning method.</p> <p>Display example 1: 24p = Refresh Rate 24 [Hz], Scan Mode: Progressive</p> <p>Display example 2: 60i = Refresh Rate 60 [Hz], Scan Mode: Interlace</p>
	ColorSamp./Depth	<p>Displays the color sampling and bit depth.</p> <p>Display example 1: YCbCr444/8bit</p> <p>Display example 2: RGB/10bit</p> <p> Notes</p> <p>When YCbCr422 is detected at the following input ports, "-" is displayed because the bit depth cannot be analyzed.</p> <ul style="list-style-type: none"> HDMI
	Color Space	<p>Displays the color space.</p> <ul style="list-style-type: none"> Auto(**): When set to [Auto], the color space that is automatically determined from the input signal is displayed instead of **. Display example: Auto(BT.709) BT.709: Displayed when the input signal is being processed using BT.709. BT.2020: Displayed when the input signal is being processed using BT.2020. <p> Notes</p> <ul style="list-style-type: none"> BT.709: Mainly used for DVDs and conventional TV broadcasts. BT.2020: Mainly used for high-quality image content such as HDR.


Display Status

Category	Item	Description
	Dynamic Range	<p>Displays the dynamic range.</p> <ul style="list-style-type: none"> • Auto(**): When set to [Auto], the dynamic range that is automatically determined from the input signal is displayed instead of **. Display example: Auto(SDR) • SDR: Displayed when the input signal is being processed using SDR. • HDR10: Displayed when the input signal is being processed using HDR10. • HDR10+: Displayed when the input signal is being processed using HDR10+. • HLG: Displayed when the input signal is being processed using HLG. <p> Notes</p> <ul style="list-style-type: none"> • SDR: Mainly used for DVDs and conventional TV broadcasts. • HDR10: This is one of the HDR standards and is mainly used for Ultra HD Blu-rays. With a brightness gradient approximately 10 times greater than SDR, this allows you to display realistic images. • HDR10+: This is one of the extended standards of HDR and is mainly used for Ultra HD Blu-rays. Its dynamic metadata allows you to process images dynamically and display images with gradations that are more suitable for each scene than HDR10. • HLG: This is one of the HDR standards and is mainly used for TV broadcasts. With a brightness gradient approximately 10 times greater than SDR, this allows you to display realistic images.
	Video Range	<p>Displays the video range.</p> <ul style="list-style-type: none"> • Auto(**): When set to [Auto], the dynamic range that is automatically determined from the input signal is displayed instead of **. Display example: Auto(Limited) • Limited(16-235): Displayed when the input signal is being processed using Limited. • Full(0-255): Displayed when the input signal is being processed using Full. <p> Notes</p> <ul style="list-style-type: none"> • Limited(16-235): Usually selected when the input signal is a YCbCr signal. • Full(0-255): Usually selected when the input signal is an RGB signal. • If images look over-exposed or under-exposed, set [Signal I/O] - [Signal Format] in the projector's menu to [Full (0-255)].
	HDCP Status/Ver	<p>Displays the HDCP status and HDCP version.</p> <ul style="list-style-type: none"> • --/--: Unsupported HDCP signal, or no signal • Fail/--: HDCP certification failed • Pass/1.4: HDCP certification passed/HDCP Ver 1.4 • Pass/2.3: HDCP certification passed/HDCP Ver 2.3



Display Status

Category	Item	Description
	Trans. Type	<p>Displays the transmission method.</p> <p>TMDS transmission method</p> <ul style="list-style-type: none"> • TMDS 10.2 G: Up to 10.2 Gbps (Be sure to use a High Speed HDMI cable) • TMDS 18 G: Up to 18 Gbps (Be sure to use a premium High Speed HDMI cable) <p>FRL transmission method</p> <ul style="list-style-type: none"> • FRL-3 9G: Up to 9 Gbps • FRL-3 18G: Up to 18 Gbps • FRL-4 24G: Up to 24 Gbps • FRL-4 32G: Up to 32 Gbps • FRL-4 40G: Up to 40 Gbps <p>(For FRL transmissions, be sure to use an Ultra High Speed HDMI cable)</p>
	Stable Time	<p>Displays the amount of operating time since the signal changed.</p> <p> Notes</p> <p>The time is reset when the signal changes, and then starts counting the usage time.</p>
	<2/3>	Displays detailed information about the input signal.
	Signal Mode	<p>Displays the signal mode.</p> <ul style="list-style-type: none"> • HDMI: When an HDMI signal is detected • DVI: When an DVI signal is detected
	AVI VIC/Chk.Sum	<p>Displays the VIC code and checksum for AVI InfoFrame.</p> <p>VIC code: Displays the determination result as a three-digit number.</p> <p>Checksum: Displays the determination result (Pass/Fail).</p> <p>Display example: 016/Pass</p>
	CLK-MHz/Frame-Hz	<p>Displays the actual measurement value of the pixel clock frequency and refresh rate.</p> <p>Pixel clock frequency [MHz]: Max. 4 digits for the integer part, 3 digits for the decimal part</p> <p>Refresh Rate [Hz]: Max. 3 digits for the integer part, 3 digits for the decimal part</p> <p>Display example: 148.500/60.000</p>
	Total-H/V	<p>Displays the total number of pixels and lines including the number of effective pixels and blanking.</p> <p>Total number of pixels per line: Max. 4 digits for the integer part</p> <p>Total number of lines per frame: Max. 4 digits for the integer part</p> <p>Display example: 2200/1125</p>
	Sync Polarity	<p>Displays the sync polarity of the horizontal and vertical sync signals.</p> <p>Horizontal Sync Polarity: Pos / Neg</p> <p>Vertical Sync Polarity: Pos / Neg</p> <p>Display example: H:Pos/V:Neg</p>
	EDID Mode	<p>Displays the EDID mode settings.</p> <p>Display example: Up to 4K60 10G</p>
	EDID HDR10+	Displays the EDID (HDR10+) mode settings.
	Equalizer Level	<p>Displays the equalizer level (HDMI IN EQ Level setting).</p> <p>Setting Value: Auto, Low, Medium, or High</p>

Display Status

Category	Item	Description
		<div> Notes</div> <div>If there is noise in the image or if it is not displayed, you may be able to improve the issue by changing [Signal I/O] - [HDMI IN EQ Level] in the projector's menu.</div>

Display Status

Category	Item	Description
	<3/3>	Displays detailed information about the input signal.
	Audio Type	Displays the audio signal type input to the connected device from the HDMI port. <ul style="list-style-type: none"> • ARC: Conventional audio data transmissions (DVD, TV broadcasting, and so on) • eARC: High-quality audio data transmissions (Ultra HD Blu-ray, and so on)
	Audio Freq/Depth	Displays the audio signal frequency and bit depth input to the connected device from the HDMI port. Display example: 44.1kHz/16bit  Notes Compressed audio formats may not be displayed.
	GCP A/V Mute	Displays the A/V Mute status of GCP packets. <ul style="list-style-type: none"> • On: This device cannot display or output video and audio. • Off: This device can display or output video and audio.  Notes If "On" is displayed, turn the connected device or this device off and then back on again. If the problem persists, unplug the projector and contact Epson for help.
	DDC Status	Displays the connected device and DDC communication status.

Trademarks

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, inc.



Other product names used herein are also for identification purposes only and may be trademarks of their respective owners.